



OPERATING MANUAL MIRROR BALLS

1




Clear the space before you work.
Make sure there are not sharp objects.

2



Unfold the ball as much as possible **before inflating.**


3



Insure the air valve is closed before inflating.

**The valve is closed when the bottom is up.*

4



Install the hose to the air pump on the front, press the **red button** to start and stop the pump.

**The pump has two connectors, front to inflate and rear to deflate.*




FRONT




REAR

5



Fill some air into the interlayer space to separate the ball layers, **shake the ball as you fill.**


6



Insert the adapter into the valve, press the **red button** to start inflating.


**Be sure to not overinflate the ball this could rupture the ball.*

7



These are the average inflation time of the different sizes on a 600W pump machine.

8




When the shape is round and **seams are almost smooth** stop the pump.

**If the ball feels overinflated, press the valve button to decompress air*

**Do not overinflate the ball, that could lower the ball's usage time.*


9

When the ball is fully inflated, **tighten the valve** again.



TO DEFLATE

1




Install the **nozzle** to the **rear connector**.




REAR

2



Turn on the pump to start taking out the air.



**You can use the ball many times. Do not fold the ball, it can cause deep wrinkles.*